

## OPERATING YOUR WATCH

### Position 1

Turn the crown clockwise to wind the watch. Several winds or a shake of the watch should get the watch running.

### Position 2


Turn crown counter-clockwise to advance the date. Take care to avoid changing the day/date between the hours of 10PM-3AM.

### Position 3

Turn the crown clockwise to advance the time.

### Screw-Down Crown

The Retrospect is equipped with a screw-down crown. The crown should screw into the case smoothly. If the crown gets stuck or feels like it is threading improperly, please unscrew the crown and try again.



## CARING FOR YOUR WATCH

### Water

Make sure the crown is screwed all the way in before engaging in any water activities to prevent water intrusion. If taken into the ocean, make sure to rinse off the watch with fresh water afterwards to prevent corrosion.

### Magnetic Fields

Be careful not to bring your watch into contact with any magnets, such as cell phones, tablets, speakers, etc. A magnetized watch will exhibit erratic timekeeping and start running either very fast or very slow. A magnetized watch will need to be demagnetized to run accurately again.

### Servicing

Your watch will require servicing every three to five years to ensure proper timekeeping and water resistance. When it is time for servicing, you may send your watch in to our workshop or a certified watchmaker.

## WATCH BRACELET INFORMATION

The Retrospect comes with a steel bracelet that uses screw links. When sizing the bracelet, please use the proper size 1.40mm flathead screwdriver in order to avoid stripping of the screws. After resizing, if screws do not stay in place, applying threadlocker to the screws will remedy the issue.

The Retrospect utilizes quick-release springbars for easy installation and removal of the bracelet. To operate, pinch the levers inward to disengage the endlink from the case.

The Retrospect features our proprietary NodeX adjustable clasp, which allows for on-the-fly micro-adjustments of the bracelet without the need for tools. To operate, press down on the button on the inside of the clasp, then extend the bracelet to your desired length. To shorten the length, the button must also be pressed down.

## TIMING AND REGULATION

Every Nodus watch is regulated to strict accuracy standards and ships with a regulation card. The regulation card shows the watch's accuracy in four respective positions when the watch is fully wound, as tested by our timing equipment.

What is written on the regulation card is not a guarantee of how the watch will perform in the respective positions, simply because there are a multitude of factors that can affect watch accuracy (temperature, power reserve level, wearing habits, etc.). If the watch is kept fully wound on the wrist, the watch should be able to perform closely to what is written.

Watch movements will generally exhibit erratic shifts in accuracy as their power reserves deplete, and the regulation process does not account for these accuracy changes. If you are unsatisfied with the accuracy of your watch, please reach out to us.

## WARRANTY

All our watches are thoroughly inspected in our Los Angeles-based facility and are covered by our 24-month warranty. Nodus Watches will assume all the costs of repairing or replacing any defective pieces. This warranty coverage is transferable in private sales.

If you need to submit a warranty claim, please send an email to [support@noduswatches.com](mailto:support@noduswatches.com) or reach us through our website.