

OPERATING YOUR WATCH

Position 1

Turn the crown clockwise to wind the watch. Several winds or a shake of the watch should get the watch running.

Position 2

If watch has date complication: Turn crown counter-clockwise to change the date. For Sector Pilot only: Turn crown clockwise to change the day.

For Sector GMT only: Turn crown clockwise to advance the GMT hand. Take care to avoid changing the day/date between the hours of 10PM-3AM.


If no date complication: Turn the crown clockwise to advance the time.

Position 3

This position only exists if watch has date complication. Turn the crown clockwise to advance the time.

Screw-Down Crown

The Sector is equipped with a screw-down crown. The crown should screw into the case smoothly. If the crown gets stuck or feels like it is threading improperly, please unscrew the crown and try again.



CARING FOR YOUR WATCH

Water

Make sure the crown is screwed all the way in before engaging in any water activities to prevent water intrusion. If taken into the ocean, make sure to rinse off the watch with fresh water afterwards to prevent corrosion.

Magnetic Fields

Be careful not to bring your watch into contact with any magnets, such as cell phones, tablets, speakers, etc. A magnetized watch will exhibit erratic timekeeping and start running either very fast or very slow. A magnetized watch will need to be demagnetized to run accurately again.

WATCH BRACELET INFORMATION

The Sector Series watches come with bracelets that use screw links. When sizing the bracelet, please use the proper size 1.40mm flathead screwdriver in order to avoid stripping of the screws. After resizing, if screws do not stay in place, applying threadlocker to the screws will remedy the issue.

The Sector Series watches utilize quick-release springbars for easy installation and removal of the bracelet. To operate, pinch the levers inward to disengage the endlink from the case.

The Sector Series also features our proprietary NodeX adjustable clasp. To operate, press down on the button on the inside of the clasp, then extend the bracelet to your desired length. To shorten the length, the button must also be pressed down.

TIMING AND REGULATION

Every Nodus watch is regulated to strict accuracy standards and ships with a regulation card. The regulation card shows the watch's accuracy in four respective positions when the watch is fully wound, as tested by our timing equipment.

What is written on the regulation card is not a guarantee of how the watch will perform in the respective positions, simply because there are a multitude of factors that can affect watch accuracy (temperature, power reserve level, wearing habits, etc.). If the watch is kept fully wound on the wrist, the watch should be able to perform closely to what is written.

Watch movements will generally exhibit erratic shifts in accuracy as their power reserves deplete, and the regulation process does not account for these accuracy changes. If you are unsatisfied with the accuracy of your watch, please reach out to us.

WARRANTY

All our watches are thoroughly inspected in our Los Angeles-based facility and are covered by our 24-month warranty. Nodus Watches will assume all the costs of repairing or replacing any defective pieces. This warranty coverage is transferable in private sales.

If you need to submit a warranty claim, please send an email to support@noduswatches.com or reach us through our website.